

Dust/Dirt Cover for Live Valves



Machines with Live valves must have dust covers to protect against contamination.

Dust Cover Blank (Part No.6V0852)

Dust Cover Engine (Part No.8C3445)

Dust Cover Transmission (Part No.8C3447)

Dust Cover Hydraulic (Part No.8C3451)

Sample Gun



Part Number 972 Source 345

Use with the provided tubing for drawing a Sample in any compartment